



Basket Set Installation Manual

TOOLS REQUIRED

Rubber Mallet

No. 2 Squarehead
Screwdriver or
Power Drill and
No. 2 Drill Bit






PARTS INDEX

PLEASE NOTE:

Not all parts required
for the 3 drawer
basket sets

- A Baskets
- B Top Crossmembers x 2
- C Bottom Crossmembers x 2
- D Left Side Frame
- E Right Side Frame
- F Braces x 2
- G Melteca Top
- H Square Head Screws x 8



Step 1)

A) Stand left side frame and right side frame with the top sitting on the floor

B) Make sure that the holes in the left and right side frames are facing away from you.

Place the bottom rear crossmember (has holes) over the rectangle hollows in the frame sides and use a mallet to knock firmly into place using a mallet.

C) Rotate the frame around and repeat with the opposite side.



Step 2)

A) Turn the frame so that the rear of the frame is now facing you. You should see screw holes approx 50mm from the tip of the frame. Place a brace over the frame uprights and bottom crossmember so that the holes line up with the holes on the frame.



B) Using a screwdriver or power drill fix the screws into place.



Step 3)

A) Turn the frame over so that the feet are now sitting on the floor.

B) Fix the top front and rear crossmembers (no holes) into place the same as step 1-B.

Step 4)

A) Fix the remaining brace into place and screw to the frame as in Step 2

Step 5)

A) Line the melteca top up with the top of the frame and press into place. The hollowed out section on the melteca top should fit over the top crossmembers.

Step 6)

Insert the baskets by placing the baskets on an angle and sliding into place.

